

Work Order ID 74072

Wednesday, September 21, 2011 10:31:43 A



Page 1

Item ID: D350-600-449

Accept



Setup Start



Revision ID:

Item Name: Switch Relocation

Stop



Start Date: 9/21/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 9/30/2011 Req'd Qty: 1.00



Customer:

Reference:

Approvals:

Process Plan:

Date: 11-09-21

Tooling:

Date:

Run Start



QC:

Date:

SPC (Y/N):

Date:

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
N/A	Rev C

100

0.00



DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Photocopy bluefile & type labels per PPP D350-600-449 CHG001

Sulor/bc

11-09-22

101

0.00



Pick Kit

Packaging

Memo

0.00

Packaging

11-09-26

110

0.00



QC4- 100% Inspect kits for completeness

QC

Memo

0.00

Quality Control

Sulor/bc

11-09-26

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 74072

Wednesday, September 21, 2011 10:31:43 A



Page 2

Item ID: D350-600-449

Accept



Setup Start



Revision ID:

Stop



Item Name: Switch Relocation

Start Date: 9/21/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 9/30/2011 Req'd Qty: 1.00



Customer:

Reference:

Run Start



Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Stop



QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
120 	Packaging	0.00							
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D350-600-449 Location: _____ PPP Rev: _____								
130 	QC21- Final Inspection - Work Order Release	0.00							
QC	Memo	0.00							
Quality Control									

_____ *Peyp 20*

_____ *u/9/27*

mf
11-09-27

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries





Wednesday, September 21, 2011 10:31:48 AM

Parent Item Name: Switch Relocation

Required Date: 9/30/2011

Required Qty: 1.00

Comments: IPP Rev:a07.03.07new issue ec

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D3597-1  Female Spade Connector		Manufactured	No			110	Each	21.0000	2	2			
				<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				st073				21					
				31200				21					
D3598-2  Expandable Sleeve 1/4"		Manufactured	No			110	f	131.7800	8	8.421053			
				<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				ST068				131.78					
				31201				15					
				36442				1					
				60277				115.78					
1- Cut 1 at 96.00" as per dwg D3599-1'  Tie Wrap		Manufactured	No			110	Each	75.0000	24	24			
				<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				ST069				75					
				66958				75					
D3600-1  Tie Wrap Mount		Manufactured	No			110	Each	62.0000	24	24			
				<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				ST069				62					
				66957				62					

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

Wednesday, September 21, 2011 10:31:48 AM

Work Order ID: 74072

Parent Item: D350-600-449

Parent Item Name: Switch Relocation

Start Date: 9/21/2011

Required Date: 9/30/2011

Start Qty: 1.00

Required Qty: 1.00

M22759/16-229

Purchased

No

110

f

200.0000

24

25.26316



122GA ELECTRICAL WIRE, 24'



SP11-09-26

Location

Loc Qty

Loc Code

ST394

200

117086

200

24

1- Cut to length as per dwg

M81824/T-2

Purchased

No

110

Each

87.0000

3

3



SPLICE



SP11-09-26

Location

Loc Qty

Loc Code

ST394

87

112691

87

3x

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

-241	-242	-243	-245	-246	-247	-248	-249	-449	Part Number	Description
X									D350-600-241	SPACEPOD™ LH, AS350
	X								D350-600-242	SPACEPOD™ RH, AS350/355
		X							D355-600-243	SPACEPOD™ LH, AS355
1		1	X						D350-600-245	DOOR ASSEMBLY LH
	1			X					D350-600-246	DOOR ASSEMBLY RH
					X				D350-600-247	SPACEPOD™ UPGRADE KIT LH
						X			D350-600-248	SPACEPOD™ UPGRADE KIT RH
							X		D350-600-249	SPACEPOD™ UPGRADE KIT
1	1	1						X	D350-600-449	SWITCH RELOCATION KIT
2	2	2							D2174-041	WEB ASSEMBLY
							1		D2464-0360	NEOPRENE SEAL
			1	1					D2589	KEYS, KEY CHAIN
1	1	1							D2985	DECAL
1	1	1			1	1	1		D3015-3	LOCK NUT
			1		1				D3186-3	SPACEPOD DOOR, LH
				1		1			D3186-4	SPACEPOD DOOR, RH
1**		1**							D3187-1	FLOOR
	1**								D3187-2	FLOOR
1									D3188-5	SPACEPOD BODY
	1								D3188-6	SPACEPOD BODY
		1							D3188-7	SPACEPOD BODY
1	1	1			1	1	1		D3547-1	BRACKET
1	1	1			1	1	1		D3550-1	STRUT
			1	1	1	1	1		D3552-7	GAS SPRING
1	1	1			1	1	1		D3554-7	BALL STUD
8	8	8							AN3-3A	BOLT
2	2	2							AN3-10A	BOLT
8	8	8							AN3H4	BOLT
1	1	1			1	1	1		AN5-5A	BOLT
36	36	36							AN525-10R7	SCREW
8	8	8			4	4	4		AN526C832R14	SCREW
7	7	7							MS24694S67	SCREW
1	1	1			1	1	1		MS24694S69	SCREW
			2	2	2	2	2		MS27039-0811	SCREW
8	8	8			1	1	1		AN3235-020-935	WASHER
8	8	8							AN960JD10	WASHER
16	16	16			1	1	1		AN960JD10L	WASHER
			4	4	8	8	8		AN960JD8	WASHER
3	3	3			3	3	3		AN960JD516	WASHER
			2	2	2	2	2		NAS1515H3	NYLON WASHER
			2	2	6	6	6		MS21042L08	NUT
16	16	16			1	1	1		MS21042L3	NUT (or MS21042-3)
1	1	1			1	1	1		MS21042L5	NUT
16	16	16							AKS7-1032-130	INSERT
28**	28**	28**							AKS7-1032-130	INSERT
								3	M81824/1-2	SPLICE

• COPYRIGHT © 2006 BY DART AEROSPACE LTD. •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: E

Date: 09.07.31

-241	-242	-243	-245	-246	-247	-248	-249	-449	Part Number	Description
								2	D3597-1	FEMALE SPADE CONNECTOR
								1	D3598-2-096	EXPANDABLE SLEEVE
								24	D3599-1	TIE-WRAP
								24	D3600-1	TIE-WRAP MOUNT
								24 FT	M22759/16-22-9	WIRE
			1*	1*	1*	1*			D2464-1250	NEOPRENE SEAL
1**		1**	1*		1*				D3567-1	DECAL
	1**			1*		1*			D3567-2	DECAL
			2*	2*					D2586	LATCH
			2*	2*					D2585	MOUNTING CHANNEL
			2*	2*					D2621	LATCH PLATE
			2*	2*					MS27039-1-15	SCREW
					2	2	1		MS27039-1-25	SCREW
			2*	2*	2	2	1		AN960JD10	WASHER
			2*	2*	2	2	1		MS21042L3	NUT (or MS21042-3)
			1*	1*					D2857-1	HINGE BRACKET
			1*	1*					D2857-2	HINGE BRACKET
			2*	2*					D2228	BACKING PLATE
			8*	8*	8	8	8		AN526C832R10	SCREW
			8*	8*	8	8	8		AN960JD8	WASHER
			8*	8*	8	8	8		MS21042L08	NUT
			1*	1*	1*	1*	1		D3557-1	BRACKET
			2*	2*	2*	2*	2		D2228	BACKING PLATE
			1*	1*	1*	1*	1		D3554-7	BALL STUD
			1*	1*	1*	1*	1		AN960JD516	WASHER
			1*	1*	1*	1*	1		D3015-3	LOCK NUT
			2*	2*	2*	2*	2		AN526C832R14	SCREW
			2*	2*	2*	2*	2		AN526C832R10	SCREW
			4*	4*	4*	4*	4		AN960JD8	WASHER
			4*	4*	4*	4*	4		MS21042L08	NUT
2**	2**	2**			1	1	1		D2237	STRIKER PLATE
4**	4**	4**			2	2	2		MS20426AD4-5	RIVET
2**	2**	2**			2	2	2		D3538-1	HINGE BRACKET
2**	2**	2**							D2179	HINGE BRACKET PLATE
4**	4**	4**			4	4	4		AN526C832R24	SCREW
4**	4**	4**			4	4	4		AN960JD8	WASHER
4**	4**	4**			4	4	4		MS21042L08	NUT

* PRE-INSTALLED ON D3186-3/-4 SPACEPOD™ DOOR

** PRE-INSTALLED ON D3188-5/-6/-7 SPACEPOD™

• COPYRIGHT © 2006 BY DART AEROSPACE LTD. •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: E

Date: 09.07.31